

If you are not able to achieve azimuth (flashing AZM on AAT display) and have used the troubleshooting tips concerning mounting, etc from the Quick Ref card. Use the following flowchart:

From startup, the AAT displays a flashing 'GPS' indicator to let you know it is attempting to LOCATE satellites. Once GPS location data has been established the AAT will flash AZM as it is attempting to calculate a GPS based azimuth reading. Once AZM is solid at any time, measurements can begin. If AZM remains flashing after 3-4 minutes, follow flowchart below

