

Sunsight AAT30 & AAT15 Nokia FASB Mounting Instructions

This document is intended as an overview for use of the Sunsight AAT30 Nokia FASB mount, required for alignment of any Nokia FASB antenna. This document assumes the user is familiar with the AAT30 and its functions. Please refer to the *AAT30, AAT15 Quick Start Guide* and *AAT30, AAT15 User's Manual* for full AAT30 operating instructions.

1. Remove 4 screws securing upper cover from FASB antenna.
2. Insert FASB mount bracket into the antenna frame slot (right side recommended).
 - a. The spring-loaded mount insert should pass through the antenna frame slot.
 - b. Use the provided screw to keep mount insert centered while fitting to antenna frame.
3. Secure mount to antenna by rotating knob clockwise until mount body seats into antenna frame.



4. Secure AAT to FASB mount and attach safety lanyard.
5. Power on AAT and establish Wi-Fi connection.
6. Set orientation to **Front**



7. Align antenna and save alignment results as described in *AAT30 Quick Start Guide* and *AAT30, AAT15 User's Manual*.
 - a. Both documents are available for download at:
<https://www.sunsight.com/index.php/support>
8. After alignment has been completed, power off AAT and remove mount from antenna.
9. Re-secure upper cover to FASB antenna.

