

## **Firmware and Android App Update For AAT/AAT Mini/AAT Max**

### **AAT Firmware and Android App Download Procedure**

- 1) Connect to the internet, not the AAT, and download the latest appropriate update zip file from [www.sunsight.com/support](http://www.sunsight.com/support). This zip file will contain the files required for the update. There may be files for the AAT update, the Android app update, as well as other documentation.
- 2) Unzip the downloaded file(s) to a known location.

**\*\* Files that end in .bin are for the AAT, files that end in .apk are for the Sunsight Android app**

### **Sunsight AAT Android App Update Procedure**

- 1) Delete the current app from the Android Device
- 2) Navigate to the location where the .apk was saved when it was unzipped above
- 3) Double click on the .apk file to install the new app. Follow on-screen instructions

### **AAT Firmware Update Procedure**

**ALL REPORTS MUST BE DOWNLOADED PRIOR TO UPDATING THE AAT FIRMWARE**

**HAVE A MINIMUM OF 50% CHARGE IN THE AAT OR CONNECT THE AAT TO THE CHARGER DURING THE FIRMWARE UPDATE PROCESS**

**DO NOT POWER OFF THE AAT DURING THE FIRMWARE UPDATE PROCEDURE! TO DO SO COULD REQUIRE RETURNING THE UNIT TO SUNSIGHT FOR REPAIR.**

FIRMWARE UPDATE IS PERFORMED OVER WIFI. FIRMWARE CANNOT BE UPDATED USING THE USB-C CABLE CONNECTION

The update process takes 3-4 minutes to complete

- 1) Connect your computer or hand-held WiFi device to the AAT's WiFi network and navigate to the Firmware Update page (Home->Tools->Firmware Update)
- 2) Record the version of firmware displayed at the bottom of the page
- 3) Select "Choose File", then browse and select the downloaded .bin file
- 4) Select "Update". During the Firmware Process the AAT will restart and the WiFi connection will be lost.
- 5) Follow the displayed on-screen instructions to determine when to reconnect to the AAT's WiFi network
- 6) Check the status of the Firmware Update process displayed at the bottom of the screen
- 7) Once the update is complete, confirm the firmware version displayed at the bottom of the Firmware Update page is higher than the one recorded in step 2) above.